

PRESSURE/TORQUE CONVERSION CHART

PRESSURE IN PSI	FT. LBS.	N-m	1MD
1000	125	169	
1200	139	188	
1400	177	240	
1600	204	277	
1800	228	309	
2000	257	348	
2200	286	388	
2400	312	423	
2600	341	462	
2800	367	498	
3000	392	531	
3200	419	568	
3400	445	603	
3600	473	641	
3800	502	681	
4000	527	715	
4200	554	751	
4400	582	789	
4600	610	827	
4800	636	862	
5000	663	899	
5200	691	937	
5400	716	971	
5600	744	1009	
5800	771	1045	
6000	795	1078	
6200	822	1114	
6400	849	1151	
6600	876	1188	
6800	904	1226	
7000	927	1257	
7200	954	1293	
7400	980	1329	
7600	1007	1365	
7800	1031	1398	
8000	1059	1436	
8200	1084	1470	
8400	1109	1504	
8600	1136	1540	
8800	1161	1574	
9000	1186	1608	
9200	1212	1643	
9400	1238	1679	
9600	1263	1712	
9800	1289	1748	
10000	1318	1787	

